

## Cautions and Warnings



**READ AND SAVE THESE INSTRUCTIONS** - Follow the instructions in this installation manual. These instructions must be followed to avoid damage to this product and associated equipment. Product operation and reliability depend upon proper installation.

**DO NOT INSTALL ANY SIMPLEX PRODUCT THAT APPEARS DAMAGED** - Upon unpacking your Simplex product, inspect the contents of the carton for shipping damage. If damage is apparent, immediately file a claim with the carrier and notify an authorised Simplex product supplier.

**ELECTRICAL HAZARD** - Disconnect electrical field power when making any internal adjustments or repairs. All repairs should be performed by a representative or authorised agent of your local Simplex product supplier.

**STATIC HAZARD** - Static electricity can damage components. Handle as follows:

- Ground yourself before opening or installing components
- Prior to installation, keep components wrapped in anti-static material at all times

## In this publication

This publication discusses the following topics:

Topic	Page
Introduction	1
Technical specifications	2
Environmental characteristics	2
Electrical characteristics	2
Operation	2
Programming the address	2
Address flag	3
Ordering information	3
Base Fixing	4
Wiring information	4

## Introduction

The 516.850.053.E 850H heat sensor measures the temperature and sends this to the 4100-6077AU *MX* Digital Loop Card in the 4100ESi fire alarm panel. The 4100ESi software can determine if an alarm or other condition, e.g., fault is present. The sensor contains a loop short circuit isolator that isolates a section of loop cabling if a short circuit is present (requires 4B-C base to be used). The sensor must be plugged into one of the following bases:

517.050.042 4B-C Continuity base

516.800.910 802SB Sounder base – Loop powered

516.800.911 901SB Sounder base – Externally powered

516.800.957 LPSB3000 Symphony Sounder base - Loop powered

516.800.958 LPAV3000 Symphony Sounder/Beacon base - Loop powered


Using the 4100ESi programmer, the sensor can be programmed for:

- Fixed temperature modes A2S, CS or Rate of Rise modes A2R, CR
- The LED to blink on poll or not

**Note:** Only when the 850H heat sensor is fitted to the 4B-C Continuity base is its in-built short circuit isolator used. When the 850H is programmed as a CS Fixed Temperature or CR Rate of Rise sensor, only the 4B-C base may be used.

# 516.850.053.E MX Digital Loop Heat Sensor Installation Guide

## Technical Specifications



**Figure 1. Overall Dimensions**

## Environmental Characteristics

- Maximum Ceiling Ambient Temperature: 45°C for A2S, A2R setting, 70° for CS, CR setting
- Humidity: up to 95% relative humidity at 32°C

## Electrical Characteristics

- Input voltage (*MX* Digital Loop): 20 to 40 VDC maximum
- Quiescent current: 290µA
- Alarm current without remote LED: 3 to 3.3 mA

Electrical characteristics at 25°C and at nominal supply voltage of 37.5V

## Operation

The heat sensor uses a single thermistor to produce an output proportional to temperature. Rate of change of temperature is determined by the panel by using differences between consecutive temperature values returned to the panel. The 850H's alarm threshold is set in the 4100ESi panel. The sensor contains a red LED that is on steady for alarm and can be programmed to flash on polling from the panel. It also has a yellow LED that lights if the internal short circuit isolator is operated.

## Programming the Address

The 850H's factory set address is 255. The address must be set to the required loop address with the 850EMT Service Tool. To do so, the 850H must be placed on the 850EMT Service Tool, as shown in Figure 2, and programmed to the required address. Infrared programming of the sensor is available with the 850EMT, however, the loop must be powered by the panel and IR mode activated at the panel. Alternatively, the device's loop address can be programmed from the 4100ESi front panel by installing and readdressing one sensor at a time.




**Figure 2. 850EMT Service Tool**

# 516.850.053.E MX Digital Loop Heat Sensor Installation Guide

## Address Flag

An address flag can be used to identify the address (the address flag holds a label which is supplied in a pack for addresses 1 to 255) and is ordered separately from the sensor. The address flag is fitted to the bottom of the sensor (see Figure 3). When the sensor is fitted to the base and turned until fully fixed, the address flag is transferred to the base. If the sensor is removed from the base, the address flag remains with the base



**Figure 3. Fitting Address Flag Carrier**

## Ordering Information

Components	Number
Heat sensor	516.800.053.E
4B-C Continuity Base	517.050.042
802SB Sounder Base – Loop powered	516.800.910
901SB Sounder Base – Externally powered	516.800.911
LPSB3000 Symphony Sounder Base – Loop powered	516.800.957
LPAV3000 Symphony Sounder/Beacon Base – Loop powered	516.800.958
Remote Indicator	E500 Mk2 Series
Address Flags (pack of 100)	516.800.915
Address Flag Labels	516.800.931

**Table 1. Ordering Information**

# 516.850.053.E MX Digital Loop Heat Sensor Installation Guide

## Base Fixing


The 4B-C base is fixed to the ceiling, electrical box or deckhead mount in the traditional manner. Refer to the appropriate installation instructions for the other specialist bases.

The 4B-C features a park position that allows the sensor to be rotated so that it is disconnected from the addressable loop wiring. The base should be fixed so that the park plunger faces toward the door or trafficable area. This allows the sensor LED to be visible from that area.

Wiring for the bases is shown in Figure 4.

The sensor is fitted to the base by rotating the sensor until it engages with the base, then rotating further to make full contact. When correctly fitted, the raised ribs on the side of the sensor should align with a similar rib on the base.

## Wiring



**Figure 4. Base Wiring Information**

Cables should be arranged at each side of the terminal screw. A maximum of two 1.5mm<sup>2</sup> cables or one 2.5mm<sup>2</sup> cable can be fitted to one terminal. Any additional cables (such as Remote Indicator) should be fitted with suitable fork or eyelet crimp terminal lugs. The installation should comply with AS 1670.1. Further wiring information is available in the 4100ESi Field Wiring Diagrams manual LT0432.

4B Loop Cabling (not normally used)	4B-I Loop Cabling (not normally used)	<b>517.050.042</b> <b>4B-C Loop Cabling</b>
L (-In/Out) L1 (+In/Out). A remote indicator may be connected between loop positive L1 (+In/Out) and terminal R (-ve). Terminal L2 must not be used	L2 (-In) M (-Out) L1 (+In/Out). A remote indicator may be connected between loop positive L1 (+In/Out) and terminal R (-ve). Terminal L must not be used	L (-In) M (-Out) L1 (+In/Out). A remote indicator may be connected between loop positive L1 (+In/Out) and terminal R (-ve). Terminal L2 must not be used

SIMPLEX is a trademark of ADT Services GmbH. MAPNET II, SAFELINC, TRUEALARM, TRUESTART are trademarks of ADT Services AG or its affiliates. MX TECHNOLOGY is a trademark of Thorn Security Limited or its affiliates. TYCO is a trademark of Tyco International Services GmbH.  
© 2016 Tyco Australia Group Pty Limited. A.B.N. 93076836416. Unauthorised use of trademarks is strictly prohibited. Printed Oct 2016